

# New Matfoot Design

---

Please note there are now wear indicator lines on the back side of the mat foot to help you gage when the matfoot is worn out.

If you cut 8-Ply mats then you should change the foot after you can no longer see the bottom half of the lowest line.

If you only cut 4-ply mats then you can let the mat foot wear until you can no longer see the lower half of the second line.

Please refer to the following images as a guide.

